

GOTTA-B-BOUNCIN INC.

Quick Check (Do's and Don'ts)

Emergency Contact Numbers (Jason Brunner)

561-703-0236

561-929-4423

Miscellaneous Rules

No shoes allowed while jumping in the units

No sharp objects, chewing gum, silly string or food of any kind is permitted inside the units.

No pets, oil, drinks, candy, sticky substances.

No rough play or flipping is permitted

Persons with neck or back injuries, or pregnant women are not permitted to jump for risk of injury.

Do not deflate the unit with anyone inside. In case of malfunction, exit the unit immediately and call us for advice or technical assistance. Refer to "Special Instructions" on the Liability Waiver.

Weight Limits:

This really depends on the size of the children. Remember adult supervision is important at all times and in determining age, size and safety of groups.

As a guideline (Use your best judgment):

Ages 3 to 8.....8 children

Ages 9 to 12.....6 children

Ages 13 to 16.....4 children

Adults are welcome to join the fun as well!

Escape Features:

In case you loose power and the inflatable begins to slowly deflate, there are escape features that will allow a safe exit of the bounce house. We will show you upon the initial inspection.

FunHouse/Slide

During the course of the party, you may want to wet or hose down the slide portion of the FunHouse as the sun, on an extremely hot day, tends to heat the slide and may or could possibly cause minor skin irritation.

Miscellaneous Suggestions:

Wear socks at all time during the hot summer months as the plastic/rubber in the bouncers can tend to get hot due to the sun and possibly cause minor skin irritation to feet.

Observe all weather conditions and take note to the wind and rain as they can change very quickly.

HAVE FUN AND BOUNCE!!!!

WIND

When conditions hit the 25-31 MPH zone, have all children exit the inflatable and turn the power to the blower off. If at any time you notice the wind starting to lift the inflatable off the ground, clear the unit of riders and turn it off until the wind subsides.

Wind Speed (MPH)	Wind Effects Observed on Land	Terms Used in NWS Forecasts
0-1	Calm; smoke rises vertically.	Calm
1-3	Direction of wind shown by smoke drift, but not by wind vanes.	Light
4-7	Wind felt on face, leaves rustle, ordinary vane moved by wind.	Light
8-12	Leaves and small twigs in constant motion; wind extends light flag.	Gentle
13-18	Raises dust and loose paper; small branches are moved.	Moderate
19-24	Small trees in leaf begin to sway; crested wavelets form on inland waters.	Fresh
25-31	Large branches in motion; whistling heard in telephone wires; umbrellas used with difficulty.	Strong
32-38	Whole trees in motion; inconvenience felt walking against the wind.	Strong

Rain

Do not use the bounce houses in rainy conditions. Wet vinyl is slippery and children are more likely to fall and knock into each other.

Leave the unit up and running in light rain as the air pressure prevents too much water from getting into the base. If the rain looks like it's going to last a while or be heavy, do the following:

- Turn the power off
- Remove the blower from the unit(s) and take indoors or to a covered area
 - Call Gotta B Bouncin INC.